



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the adhesive tape covers on the ProClip. Press the upper corner of the grooved edge on the right part of the ProClip into the gap between the control panel and the dashboard.



2. Press forwards on the right side of the ProClip, follow through downwards so all of the grooved edge goes into the gap. Press until you hear/feel it snaps into place.

3. The ProClip is in place.

4. The ProClip is in place.



Az alábbiakkal kompatibilis

- Audi Q7 (2006-2015)

