



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of adhesive tape on the ProClip. Press the angled edge on the lower part of the ProClip into the seam/gap inside the air vent bottom and the surrounding panel frame.



2. Press down on top of the ProClip and hook the grooved edge into the air vent panel frame edge.

3. The ProClip is in place.

4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Toyota Yaris 4-doors (2007-2011)

