



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of adhesive tape on the ProClip. Press the angled edge on the lower part of the ProClip into the gap between the lower part of the air vent and the surrounding panel frame.



2. Press firmly down on top of the ProClip and insert the grooved edge on the upper part of the ProClip into the air vent. Release the pressure so the edge of the panel frame surrounding the air vent fits into the grooved edge on the ProClip.

3. The ProClip is in place.

4. The ProClip is in place.



Az alábbiakkal kompatibilis

- Dodge Caliber (2007-2009)
- Jeep Compass (2007-2008); Jeep Patriot (2007-2008)

