

TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the adhesive tape covers on the ProClip. Hook the angled edge on the left part of the ProClip into the gap between the frame surrounding the control panel and the dashboard.



2. Hook the angled edge on the right part of the ProClip into the gap between the control panel and the surrounding frame.

3. The ProClip is in place.

4. The ProClip is in place.



Az alábbiakkal kompatibilis

- Subaru Legacy (2007-2009); Subaru Outback (2007-2009)

