




TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of the adhesive tape on the ProClip. Press the angled edge on the right part of the ProClip into the gap between the panel surrounding the gear shift and the console.



2. Press downwards on the left side of the ProClip so the angled edge hooks under the console edge.

3. The ProClip is in place.

4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Skoda Superb (2007-2008)

