



# TELEPÍTÉS

## ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the adhesive tape covers on the ProClip. Place the ProClip onto the dashboard edge.

2. Press down on the ProClip so the adhesive tapes attach to the dashboard.



3. The ProClip is in place.

4. The ProClip is in place.

## Az alábbiakkal kompatibilis

- Scania R-series (2005-2009)

