



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the panel frame surrounding the information screen and the dashboard ledge, to widen the gap. Press down on the thick end of the gap opener to widen the gap even more. Keep the gap opener in this position and press the grooved edge on the lower part of the ProClip into the gap next to the gap opener.



2. Press the lower edge all the way into the gap. Pull out the gap opener.



3. Press the gap opener into the gap between the panel frame surrounding the information screen and the dashboard. Press firmly forward on the upper part of the ProClip so the grooved edge goes into the gap next to the gap opener. Press until you see or hear/feel it click into place. Pull out gap opener.

4. The ProClip is in place.

NOTE: The air vent will open and close freely with the ProClip attached.



Az alábbiakkal kompatibilis

- Jaguar XF (2009-2015)