



# TELEPÍTÉS

## ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the center console and the dashboard, to widen the gap. Peel off the adhesive tape covers on the ProClip. Press the angled edge on the right part of the ProClip into the gap between the trim and the dashboard.



2. Flip the ProClip lefward/forward so the angled right edge hooks behind the trim.

3. Hook the angled edge on the left part of the ProClip into the gap below the gap opener. Press forward on the left side of the ProClip so the angled edge goes all the way into the gap. Pull out the gap opener.



4. The ProClip is in place.

## Az alábbiakkal kompatibilis

- Ford Falcon FG-series (2008-2010)

