



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the cover of adhesive tape on the ProClip. Open the glove compartment door. Hook the curved edge on the lower part of the ProClip around the dashboard edge.



2. Place your index fingers behind the ProClip. Push it upwards and hook the angled edge over the dashboard edge. Close the glove compartment.

3. The ProClip is in place.

4. The ProClip is in place.



Az alábbiakkal kompatibilis

- Jeep Compass (2009-2016); Jeep Patriot (2009-2017)

