



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the cover of adhesive tape on the ProClip. Hook the angled edge on the right side of the ProClip over the console edge.



2. Place your thumb onto the upper part of the ProClip. (Behind the face plate) Push firmly forward on the ProClip. The ProClip will now flex forward. Press until the angled edge on the left back part of the ProClip hooks around the sidewall edge by the carpet.

3. The ProClip is in place.

4. The ProClip is in place.



Az alábbiakkal kompatibilis

- Mazda RX-8 (2008-2012)

