



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the cover of adhesive tape on the ProClip. Press the grooved edge on the upper part of the ProClip into the upper air vent edge.



2. Press firmly upwards on the bottom part of the ProClip so it flexes upwards, and hook the grooved edge onto the lower air vent edge.

3. The ProClip is in place.

4. The ProClip is in place.



Az alábbiakkal kompatibilis

- Jeep Grand Cherokee (2011-2020)

