

TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Place the angled edge on the upper part by the gap between the speaker vent and the dashboard. Press downward on top of the ProClip so the speaker vent flexes slightly.



2. Pull the upper edge of the ProClip toward you so the angled edge hooks under the dashboard.

3. Pull the ProClip toward you and hook the angled lower edge under the upper edge of the air vent.

4. The ProClip is in place.



Az alábbiakkal kompatibilis

- Holden Commodore Berlina (2011-2012); Holden Commodore Calais (2011-2012); Holden Commodore Omega (2011-2012)

