



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Press the angled edge on the lower part of the ProClip into the gap between the climate control panel and the surrounding frame.



2. Press the upper part of the ProClip downward so the ProClip flexes. In the same time, press the upper part forward and release the pressure so the angled upper edge goes into the gap between the climate control panel.



3. Press downward on the lower part of the ProClip, and upward on the upper part of the ProClip so both angled edges go all the way into the gaps and the adhesive tapes attach.

4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Nissan Patrol (1998-2010)

