



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the instrument panel and the dashboard, to widen the gap.



2. Press the angled edge on the right part of the ProClip into the gap below the gap opener. Flip the ProClip forwards/leftwards so the angled right edge hooks behind the frame surrounding the instrument panel. Pull out the gap opener.



3. Press the gap opener into the gap between the frame surrounding the control panel. Press forward on the left side of the ProClip so it goes all the way into the gap between the gap opener. Pull out the gap opener.

4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Ford Territory (2012-2014)

