



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Hook the angled edge on the upper part of the ProClip into the gap in the coin compartment.



2. Press the ProClip forward and hook the angled lower edge into the gap between the upper and the lower section of the dashboard. Press upward on the lower part of the ProClip so the angled edge goes all the way into the gap.

3. The ProClip is in place.



4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Toyota HiLux (2016-2015)

