



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. A mellékelt alkoholos kendő segítségével tisztítsa meg azt a területet, ahová a ProClip kerülni fog. Press the thin end of the enclosed gap opener into the gap between the control panel and the dashboard. Peel off the adhesive tape covers on the ProClip. Press the curved edge on the upper part of the ProClip into the gap next to the gap opener.



2. Flip the ProClip downward so the curved upper edge hooks behind the control panel. Pull out the gap opener.



3. Press the gap opener into the gap between the frame surrounding the air vent and the center console. Pull the ProClip downward. Hook the angled edge on the lower part of the ProClip into the gap next to the gap opener. Press upward on the lower part of the ProClip so the angled edge goes all the way into the gap. Pull out the gap opener.

4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Ford Escape (2020-2019); Ford Kuga (2017-2019)

