



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. A mellékelt alkoholos kendő segítségével tisztítsa meg azt a területet, ahová a ProClip kerülni fog. Press the thin end of the enclosed gap opener into the gap between the center console panel frame and the console edge, to widen the gap. Peel off the cover of adhesive tape on the ProClip.



2. Hook the angled edge on the left side of the ProClip around the center console edge.

3. Place your index fingers underneath the ProClip and your thumbs on top of the ProClip. Pull the ProClip slightly towards you. Hook the angled edge over the console edge and into the gap above the gap opener. Pull out the gap opener.



4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Ford Escape (2020-2019); Ford Kuga (2013-2019)

