



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip. It is very important to place this ProClip in the exact same position as shown in the pictures. This ProClip consists of two parts:

Part 1: Attaching part (the smallest part)

Part 2: ProClip face plate



1. Press the thin ends of the enclosed gap openers into the gap between the control panel and the surrounding frame, to widen the gap. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on Part 1. Place the lower edge of Part 1 about 3 mm below the seam in the center console. Press the angled edge on Part 1 into the gap between the gap openers.



2. Press Part 1 forward, in the same time flip it leftward so the angled edge goes all the way into the gap and hooks behind the control panel and the adhesive tape attaches. Pull out the gap openers.



3. Open up the predrilled holes in Part 2 with a screwdriver. Peel off the adhesive tape cover on Part 2. Place Part 2 onto Part 1 so the holes match and the adhesive tape is on the right side. Attach Part 2 onto Part 1 by using the enclosed screws.

4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Mercedes Benz Citan (2013-2021)