

TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the angled thin edge of the enclosed gap opener into the gap between the air vent and the surrounding frame, to widen the gap. A mellékelt alkoholos kendő segítségével tisztítsa meg azt a területet, ahová a ProClip kerülni fog. Peel of the adhesive tape cover on the ProClip. Hook the curved edge of the lower part of the ProClip over the frame surrounding the air vent.



2. Press the upper part of the ProClip downward/forward. Release the pressure so the angled edge goes into the gap next to the gap opener.



3. Pull out the gap opener. Press the upper part of the ProClip upward so the angled edge goes all the way into the gap.

4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Mazda BT 50 (2013-2015)

