

TELEPÍTÉS

ProClip



Please read the instructions and look at the pictures before installing the ProClip.

1. Press the thin end of the enclosed gap opener into the gap in the center console side wall. A mellékelt alkoholos kendő segítségével tisztítsa meg azt a területet, ahová a ProClip kerülni fog. Peel off the adhesive tape covers on the ProClip.



2. Place the angled edge on the right part of the ProClip over the center console frame.

3. Press forward on the left side on the ProClip so the curved edge hooks into the gap below the gap opener. Press on the left part of the ProClip so the curved edge goes all the way into the gap. Pull out the gap opener.



4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Toyota Aurion (2013-2017)

