



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip. This ProClip can be placed on desired position along the width of the panel.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the enclosed gap openers into the gap surrounding the information display in the central control panel, to widen the gap. Remove the adhesive tape cover on the ProClip. Press both the gap openers downward to flex the panel outward. At the same time hook the curved bottom part of the ProClip into the gap next to the gap openers. Remove the gap openers.



2. Press the angled upper edge of the ProClip forward/upward into the gap between the central console panel and the dashboard.



3. Press downward on the upper part of the ProClip, making sure the adhesive tape really fastens.

4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Dacia Logan (2013-2021); Dacia Sandero (2013-2021)

