



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Hook the angled edge on the upper part of the ProClip over the panel frame surrounding the information screen.



2. Push firmly on the lower part of the ProClip to flex the ProClip forward and the lower angled edge hooks around the bottom edge of the panel frame.

3. The ProClip is in place.

4. The ProClip is in place.



Az alábbiakkal kompatibilis

- Tesla Model S (2013-2020); Tesla Model X (2016-2020)

