



TELEPÍTÉS

ProClip



Please read the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Insert the thin end of the enclosed gap opener into the gap between the padded center console side and the plastic trim behind, to widen the gap.



2. Align the right side of the ProClip so that the bottom of the angled right edge is positioned just above the silver trim on the left side of the center console. Take notice of the alignment of the left edge of the ProClip and adjust the gap opener so it is positioned just below the left edge of the ProClip. Important: do not insert the right edge into the gap yet! Remove the adhesive tape cover on the ProClip.



3. Insert the s-shaped left edge of the ProClip into the gap above the gap opener. Flip the ProClip rightward so the angled edge goes behind the console panel. Remove the gap opener.



4. Pull the front part of the ProClip slightly toward you so the angled right edge hooks into the gap between the padded part of the console side wall and the climate control panel. The ProClip is in place.

Az alábbiakkal kompatibilis

- Ford Edge (2015-2018)