



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap on the right side of the panel surrounding the upper center vents and the top of the dashboard, to widen the gap on the side and the front. Remove the adhesive tape cover on the ProClip.



2. Insert the angled upper edge of the ProClip into the gap created on the front side of the panel surrounding the upper center vents. Remove the gap opener.



3. Pull the lower part of the ProClip toward you, while keeping the ProClip flexed hook the angled lower edge of the ProClip around the top part of the air vent frame.

4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Toyota Camry (2015-2017)

