



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before installing the ProClip.

1 Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape cover on the ProClip. Press the angled right edge of the ProClip into the gap between the frame surrounding the speedometer and the dashboard.



2. Push the ProClip leftward so the angled edge slides under the frame surrounding the speedometer. Hook the angled left edge of the ProClip around the right edge of the frame surrounding the air vent. Press on the ProClip to make sure the adhesive tape attaches properly.



3. The ProClip is in place.

4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Ram Pick Up 1500 (2019-2026)

