



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip. The photos do not illustrate the correct dash but the installation is made the same way.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the cover of adhesive tape on the ProClip. Place the angled edge on the right side of the ProClip over the ring surrounding the center instrument panel.



2. Insert the thin end of the enclosed gap opener into the gap by the panel edge surrounding the air vent, to widen the gap. Push forward on the left side of the ProClip so it flexes forward and the angled edge hooks around the panel edge below the gap opener. Remove the gap opener.



3. The ProClip is in place.

4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Mini Cooper (2016-2021); Mini One (2016-2018)

