



TELEPÍTÉS

ProClip



Please read the instructions and look at the pictures before installing the ProClip.

Note: This ProClip can also be placed on the left side of the center console.



1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape covers on the ProClip. Insert the lower angled edge of the ProClip into the gap on the lower inside of the air vent. Make sure the right side of the ProClip aligns with the gap next to the padded part of the center console, according to the picture.

2. Slide the ProClip rightward until it is centered on top of the padded side of the center console. Move the ProClip forward/upward, at the same time flex the upper angled edge of the ProClip downward.



3. Insert the angled upper edge of the ProClip into the gap on the upper inside of the air vent. Make sure the adhesive tape fastens properly.

4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Toyota Fortuner (2016-2024)

