



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before installing the ProClip.

1. Insert the thin end of the enclosed gap opener into the gap dividing the center control panel, to widen the gap. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape cover on the ProClip. Insert the angled lower edge of the ProClip into the gap next to the gap opener.



2. Move the ProClip upward/forward so the angled lower edge goes into the gap and hooks behind the panel. Remove the gap opener. Insert the upper angled edge into the gap on the lower inside of the air vent. Make sure the cut outs fit into the gap.



3. Press the upper edge of the ProClip downward so the adhesive tape fastens properly.

4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Holden Commodore VF (2016-2017)

