



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape covers on the ProClip. Insert the lower angled edge of the ProClip into the gap between the dashboard overhang and the center console panel.



2. Hook the angled upper edge of the ProClip around the edge of the air vent on top of the dashboard.

3. Press down on top of the ProClip so the edge is properly in place.

4. The ProClip is in place.



Az alábbiakkal kompatibilis

- Ford Ranger (2016-2022)

