



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape cover on the ProClip. Place the curved lower edge of the ProClip under the inner silver ring surrounding the information display.



2. Press the ProClip forward until the angled upper edge hooks under the padded part of the dash top.

3. The ProClip is in place.

4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Mini Clubman (2016-2023)

