



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape cover on the ProClip. Hook the angled right edge of the ProClip around the edge of the left console side panel.



2. Press downward on the left side of the ProClip until the angled left edge hooks behind the lower edge of the left side of the console side panel.

3. The ProClip is in place.

4. The ProClip is in place.



Az alábbiakkal kompatibilis

- Audi TT (2015-2023)

