



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Place the lower edge of the ProClip into the lower part of the air vent.



2. Press the upper part of the ProClip downward so the ProClip is pressed together. Press the upper edge of the ProClip forward into the upper part of the air vent.

3. The ProClip is in place.

4. The ProClip is in place.



Az alábbiakkal kompatibilis

- Renault Clio IV (2017-2019)

