



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the enclosed gap opener into the gap between the frame around the climate control panel and the dashboard, to widen the gap. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the cover of adhesive tape on the ProClip.



2. Press the lower angled edge of the ProClip into the gap next to the gap opener. Rotate the ProClip upward so the angled edge on the lower part hooks behind the lower dashboard panel. Then place your index fingers underneath the upper part of the ProClip and pull upward to hook the upper angled edge of the ProClip over the air vent edge. Pull out the gap opener. The gap between the vent frame and inside of the vent is a tight seam. To make the upper angled edge of the ProClip go all the way into the seam between the air vent and the surrounding panel frame, pull the ProClip towards you and press down at the same time. It might need to be wiggled a little. Listen for the click as the ProClip goes into place.



3. The ProClip is in place.

4. The ProClip is in place.



Az alábbiakkal kompatibilis

- Jeep Compass (2017-2021)