

TELEPÍTÉS

ProClip









Please read all of the instructions and look at the pictures before attaching the ProClip.

- 1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the right corner on the lower part of the ProClip into the gap between fram surrounding the air vent and the dashboard. Press the lower part of the ProClip upward so all of the angled edge goes into the gap.
- 2. Press the upper part of the ProClip foward and hook the upper edge into the gap between the dashboard and the display.
- 3. The ProClip is in place.
- 4. The ProClip is in place.

Az alábbiakkal kompatibilis

• Mazda CX-5 (2017-2020)