



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Hook the notched edge on the upper part of the ProClip under the panel surrounding the display.



2. Press the lower edge of the ProClip upward and place the notched edge over the frame around the vent.

3. The ProClip is in place.

4. The ProClip is in place.



Az alábbiakkal kompatibilis

- Honda Accord (2018-2022)

