



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Place the grooved edge on the right part of the ProClip onto the frame surrounding the air vent.



2. Press the ProClip rightward and press the left edge into the air vent. Press on the left side of the ProClip so the grooved edge snaps onto the frame surrounding the air vent.

3. The ProClip is in place.

4. The ProClip is in place.



Az alábbiakkal kompatibilis

- Subaru Impreza (2017-2023); Subaru XV (2017-2023)

