



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Hook the grooved edge on the lower part of the ProClip over the frame surrounding the air vent.
2. Press downward/forward on the upper part of the ProClip. Hook the grooved edge under the frame surrounding the air vent.



3. The ProClip is in place.
4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Mitsubishi Eclipse Cross (2018-2026)

