



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Press the lower edge on the ProClip into the lower part of the air vent. Hook the grooved lower part of the ProClip over the edge of the frame surrounding the air vent.



2. Press the upper part of the ProClip downward/forward so the upper edge goes into the upper part of the air vent and the adhesive tape attaches.

3. The ProClip is in place.

4. The ProClip is in place.



Az alábbiakkal kompatibilis

- Citroen C4 Cactus (2018-2023)

