



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the center console and the dashboard, to widen the gap. Peel off the adhesive tape cover on the ProClip. Place the left edge of the ProClip, with adhesive tape, onto the right side of the frame surrounding the air vent.



2. Press forward on the right side of the ProClip so the right edge of the ProClip hooks into the gap above the gap opener. Pull out the gap opener.



3. The ProClip is in place.

4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Ram Pick Up 1500 (2019-2026)

