



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Hook the notched edge on the left part of the ProClip onto the frame surrounding the air vent.



2. Press the ProClip leftwards, then forward so the right edge hooks onto the frame surrounding the air vent.

3. The ProClip is in place.

4. The ProClip is in place.



Az alábbiakkal kompatibilis

- Subaru Ascent (2018-2026)

