



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the center console frame and the dashboard, to widen the gap. Peel off the adhesive tape cover on the ProClip.



2. Hook the angled edge on the right side of the ProClip over the left edge of the air vent.

3. Push firmly forward on the left side of the ProClip so the angled edge hooks into the gap below gap opener. Pull out the gap opener.



4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Dodge Ram (2019-2027)

