



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the angled edge on the lower part of the ProClip into the gap between the frame surrounding the air vent and the dashboard.



2. Press the upper part of the ProClip firmly downward so it flexes. Press the upper part forward and carefully release it so the angled upper edge goes into the gap between the frame surrounding the air vent and the dashboard.

3. The ProClip is in place.



4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Mitsubishi Colt (2023-2026)
- Renault Clio V (2020-2026)

