



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Hook the upper part of the ProClip over the dashboard overhang.



2. Press the angled edge on the lower part of the ProClip into the gap between the panel and the dashboard overhang.

3. The ProClip is in place.

4. The ProClip is in place.



Az alábbiakkal kompatibilis

- Peugeot 208 (2020-2026); Peugeot 2008 (2020-2026)

