



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder/equipment is to be attached after the ProClip is in place.



1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Hook the grooved upper edge of the ProClip under the frame surrounding the air vent.

2. Press the lower part of the ProClip forward/upward so the grooved edge hooks over the frame surrounding the air vent.

3. The ProClip is in place



4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Mitsubishi L200 (2020-2024)

