



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder/equipment is to be attached after the ProClip is in place.



1. Press the thin end of the enclosed gap opener into the gap between the trim and the control panel, to widen the gap. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the lower edge of the ProClip into the gap between the trim and the control panel.



2. Press forward on the ProClip so the upper part hooks into the gap next to the gap opener. Pull out the gap opener.

3. This ProClip can also be placed onto the right air vent.

4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Ford F-Series 150 (2021-2026)

