



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Insert the thin end of the enclosed gap opener into the gap between the frame surrounding the air vents and the edge surrounding the information display, to widen the gap. Remove the adhesive tape cover on the ProClip.



2. Press the angled right edge of the ProClip into the gap next to the gap opener. Remove the gap opener.



3. Insert the thin end of the gap opener into the gap between the frame surrounding the air vents and the dashboard, to widen the gap. Press forward on the left side of the ProClip allowing the angled left edge to enter the gap below the gap opener. Press the edge all the way into the gap. Remove the gap opener.

4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Renault Austral (2022-2026); Renault Mégane E-TECH (2022-2026); Renault Scénic E-TECH (2025-2026)

