



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder/equipment is to be attached after the mount is in place.



1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Hold the mount so the attaching parts on the back are to the right. Peel off the adhesive tape cover. Hook the lower edge of the mount over the frame surrounding the air vent.



2. Press forward on the top of the mount so the upper edge snaps/clips under the the frame surrounding the air vent.

3. The ProClip mount is in place.

4. The ProClip mount is in place.

Az alábbiakkal kompatibilis

- Porsche 911 (Type 992) (2020-2026)

