



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder/equipment is to be attached after the mount is in place.



1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Place the lower edge of the mount into the air vent housing.



2. Press the top of the mount forward so the upper edge hooks into the air vent housing. Make sure the grooves of the edges conform to the air vent housing and press on the insides of the mount to make sure the tape makes full contact with the trim.

3. The mount can be placed anywhere within the width of the air vent provided that installed devices/equipment will not interfere with view or access.

4. The ProClip mount is in place.



Az alábbiakkal kompatibilis

- Hyundai Santa Fe (2024-2026)