



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder/equipment is to be attached after the mount is in place. This mount consists of two parts: An attaching piece and a faceplate.



1. Hook the attaching piece around the dashboard panel behind the screen.

2. Hook the faceplate around the frame surrounding the air vent. Place the faceplate over the attaching piece so the holes match.



3. Attach the faceplate onto the attaching piece with the included screws. Adjust the parts and tighten the screws so the mount sits properly in place.

4. The ProClip mount is in place.

Az alábbiakkal kompatibilis

- Peugeot 3008 (2025-2026); Peugeot 5008 (2025-2026)

