



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder/equipment is to be attached after the mount is in place.



1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Hook the lower edge of the mount into the gap between the air vent housing and the surrounding frame.



2. Press upward and forward on the lower part of the mount.

3. Press forward on the lower part of the mount so the lower edge hooks over the frame surrounding the air vent.



4. The ProClip mount is in place.

Az alábbiakkal kompatibilis

- Kia Sorento (2025-2026)